

19. Heating


Turn on the heating by pressing the top button on the remote control, after which the fuel pump will make a click every second.
After 5 minutes, the heating will begin to work.



Turn off the heating by pressing the top button on the remote control.

20. WIFI Internet

Mobile access point is under the 12v control panel behind the couch of seats must always be included in electricity for tracking and internet access.



Use the net name and passport specified in boat documents.