5. Instruments

Yacht is equipped with the following instruments on board: VHF-AIS Garmin located in skipper corner of saloon on starboard ..



Garmin GMI[™] 20, GHC[™] 20 Autopilot Display located near by starboard helm. There is also a remote control of bowthruster Quick (**maximum time of continuous operation 5 seconds**).



Charter plotter Garmin GPSMAP® 943xsv and compass are located at the cockpit table.



Auxiliary Garmin GMI™ 20 is located near by portside helm



IMPORTANT: Please never change the English language, do not reduce the brightness, do not change the settings and alarm.