

15. Propane and stove

The propane tank locker is located in the cockpit at the helm seat on the port side.

To use:

- Open the manual shut offs on the propane drum.
- Open the manual shut offs of the pipeline in the galley under the shelf above the stove.
- To light the stove, push the knob in, turn the knob you want 90 degrees counter-clockwise, and light the burner (to light oven put the flame in the tube that is inside/center bottom).
- Hold the knob in for 10-15 seconds, then release. Make sure that the flame goes all the way around. Reduce any wind that may hinder this.

In the event that the propane smell goes off follow these steps:

- **Close the both valve on the propane tank and pipeline.**
- **Switch -off all electricity on board, bilges, water, shower pump.**
- **open up the bilges and hatches. Point the boat downwind and use the manual bilge pump to pump out the bilges.**
- **Call technical support.**

Propan stove



Pipeline valve



Drum valve

